

ДАНИЯ

Шкаф 3-створчатый №4




 **TIMBERICA**


RU Инструкция по сборке

EN Assembly instruction

FI Koontaohje



1006
82




1004
30



1038
76



1008
8



1096
48



1097
48




1027
8




1028
8




1040
20




1047
2




1042
3




1099
2




1020
5






1024
9




1049
2











8



9



10

