



АЙНО

Шкаф книжный №6, №7



№6




№7




RU Инструкция по сборке

EN Assembly instruction

FI Koontaohje




1006	
№6	№7
36	60



1008	
№6	№7
12	20



1027	
№6	№7
12	20




1096	
42	



1097	
42	




1028	
№6	№7
12	20




1074	
№6	№7
3	7









1004	
32	




1048	
№6	№7
3	5














7




8







№6, №7



№7

