


2-54

2-49, 2-50

Низ / Bottom / Alapuoli



 **TIMBERICA**


RU Инструкция по сборке

EN Assembly instruction

FI Koontaohje



1006
48



1004
28



1038
70



1008
16



1096
28




1097
28




1027
16



1028
16



1070
2



1042
2




1010
8




1040
8




1013
18




1072
4




1071
4





1034
1





1049
4













1




2









6




7



8



9



10

