


2-25

2-26


Низ / Bottom / Alapuoli




RU Инструкция по сборке

EN Assembly instruction

FI Koontaohje



1006
48



1004
26



1038
20



1008
11



1096
16





1097
16



1027
8




1028
8




1053
4



1010
4



1074
2



1049
2

